


The LEGO logo is displayed in its characteristic white font on a red rectangular background.

4000014


The LEGOLAND® Train



 LEGO.com



1



2




3





4









1





2







3





4







5




6





7




1x


1x

8



1

2








9




5



10





2



1





3




4





5







6



11





3




4






5



6






7




8







9



10






11




2




3



12




13






14




15





16




17





18




19






20




21






2x

22




2x

23






24





25






26






27





28





1



2



3



4






5





29








30



12





3



4






4x

5



3x

6




4x

4x

2x

6x


7




3x

8





9





12x



6x



6x



6x

10

1



2



3




4




5




6x





11



12





6x

13



1x

1x



1x

14





15




16



12x


17



8x



8x

18







19




20






21



13





Customer Service

Kundenservice
 Service Consommateurs
 Servicio Al Consumidor

LEGO.com/service or dial



1 00800 5346 5555

1 800-422-5346





THE
INSIDE TOUR

10 YEARS

2005/2006



2007



2008



2009



2010



2011



2012



2013



2014



Join the community on ReBrick.com



ReBrick is a social media platform where adult users can share and discuss user-created LEGO content online. It is a public stage for LEGO fans to share their wonderful models and creations with the general public.

Credits: Dave and Stacy Starlin/Imagine Rigney



REBRICK

- from LEGO Fan to LEGO Fan



Message Boards

WANT TO CHAT
with others about your
favourite LEGO themes

Ever dream of being a Caveman, Aztec Warrior, Gladiator or Viking? Need an outlet for your LEGO related creativity? The award-winning LEGO.com message boards are the place for you!



All in a safe, friendly, fun and creative environment together with thousands of like-minded LEGO fans from all around the world! Why not check them out and start posting today? You can join in the fun at:

<https://community.lego.com/>



**ON OUR ALL NEW PLATFORM,
YOU CAN:**

- Make friends
- Discuss all current and past themes
- Roleplay
- Write stories
- Earn cool ranks, like Viking, Conquistador and Roman Soldier
- Take part in polls
- "Like" content and have your own content "liked" by others
- Be interviewed by the Children's Community Team
- Get exclusive information on upcoming LEGO products and news



<https://community.lego.com>

The LEGOLAND® Train

When the first LEGOLAND® Park opened in Billund in 1968, the main attraction was a LEGO® train that carried visitors around the park. This beloved train ride has been a part of the LEGOLAND experience ever since.

This is the story of how that train came into existence.

The history of the LEGOLAND train begins in the early 1960s, when talk of creating a LEGOLAND Park first started within the walls of the LEGO Group. The idea was driven by the then owner of the LEGO Group, Godtfred Kirk Christiansen. The thoughts about the new park included the idea of a train to carry visitors. Plans to create a LEGOLAND Park had to be postponed, and it was instead another famous Danish amusement park that got the honour of having a LEGO train to carry visitors around.

In 1967 Dagny Holm, the head of the model building department at the LEGO Group, got the task of designing a LEGO train which was to be used at the Tivoli Gardens in Copenhagen. The deadline was tight, but she quickly managed to create a beautiful LEGO model of a train. Dagny Holm's model was then scaled up and became the Tivoli LEGO train. In November 1967 the LEGO train was sent to New York to promote Denmark in the American department store Macy's world famous Thanksgiving Day Parade.

The first LEGOLAND Park opened in Billund in 1968. One of the main attractions was a LEGO train carrying visitors around the park. The LEGOLAND train was an exact copy of the train Dagny Holm designed for Tivoli one year earlier. The only difference

was that the LEGOLAND train ran on rails, whereas the train in Tivoli had rubber wheels. The rails used for the LEGOLAND train allegedly came from a track in a disused brickworks outside Billund.

A former LEGOLAND employee, director of development Hans Jørgen Pedersen, remembers that when the train was installed in the LEGOLAND Park it rode in the opposite direction. Before the opening of the park it was decided to change the direction of the train to the present one. The problem with the first route was that the train had to climb a hill on its journey through the park. Whenever it rained the rails became so slippery that the train could not climb the hill and thus the LEGOLAND employees

had to gather around the train to push it uphill. The decision to switch direction meant that the train now had to run down the hill instead of climbing it. Changing the direction of the train meant making extensive alterations to the train itself. All doors on the train coaches had to be placed on the other side in order for the passengers to be able to enter the coaches from the platform.

Over the years the design of the LEGOLAND train has been altered. In 1973 another LEGOLAND Park opened, this time in Sierksdorf, Germany. One of the original amusements in LEGOLAND Sierksdorf was of course a LEGO train to carry the visitors around. The train in Sierksdorf looked slightly different compared to the original LEGO train, with the roof of each train coach given a more rounded appearance. The LEGOLAND Park in Sierksdorf closed in 1976 after just three years. As a result of this the newer and more modern LEGOLAND train from Sierksdorf was moved to Billund to replace the old LEGOLAND train from 1968. Even though some of the train parts undoubtedly have been replaced, the LEGOLAND train in Billund has the exact same design as the train that was brought home from Sierksdorf in 1976.



