



40154



1



2





3



4







1




1x



4x

2





1x




3x



2x

3



6





2x



1x


4





3x

5



8



2x





1x




2x


6








7







8







9







10






11






12







1x



1x


13






4x


14






15





16






17





2x





1x



1x

18






19





2x



1x

20





2x




2x



2x

21


1




2



2x





2x




1x



1x

22





23





2x




2x




2x


24



2x



25





1x



1x




2x

26

1



2



3





2x



2x



2x

27






1x



2x

1



1x

2



1x

3




28



1x

4




1x



1x

5





1x



5x




2x




2x

29









30








31





Customer Service
Kundenservice
Service Consommateurs
Servicio Al Consumidor
LEGO.com/service or dial

00800 5346 5555 :     
 1-800-422-5346 :  

LEGO and the LEGO logo are trademarks of the/son't des marques de commerce
 du/d'un marcas registradas de LEGO Group. ©2015 The LEGO Group. 6112846

