



40138



LEGO.com/creator

1



2



3




4






1



1x

2



3





2x



1x

3




4



2x

4






3x



1x

5




6



1x

6






1x



1x

7



8



2x



2x

8





1x

9





1x



1x

10





1x

11



12




4x



4x

12





2x



4x



1x



2x



1x

13

1




2



3








1x



2x

14





2x



2x



2x



2x

15


1



2



2x






2x




2x

16




2x





2x

17





2x



1x



1x

2

1



20





1x

3



1x



1x

4





1x



1x

5



22




1x


6



7




18






1x


19





2x

20





1x



1x




1x



1x


21



2




3





6x


22





1x

1




28



1x

2






1x




1x

3



2x

4






1x



2x

5






2x



1x

6






2x



2x

7






2x



4x

8






2x




4x

9






4x



2x

10






2x




4x



2x

11





2x



1x



1x




1x



1x

12





1x



2x



2x



2x



1x

13

1




2



3







1x



1x



1x



1x

14





1x




1x




2x

15









1x

1



2x

2






1x



2x


3





2x

4





1x




2x



1x


5





1x

6





2x

7






2x



2x

8



2x






2x



2x

9





4x



4x




4x



4x

10






2x



4x


11





2x

12






4x



4x



4x



13



2x

14





1x



2x



2x

15






2x




4x

16



2x





4x

17





1x



2x

18





2x

19






2x

20







1x

1



1x

2





1x

3



1x



1x

4





1x



1x



1x



1x



1x

5



1



2





1x

6





1x



1x






1x



1x

7





1x

8







13x
614101



6x
306201



2x
4504369



5x
302301



2x
302101



2x
379501



1x
303401

70



2x
6037277



1x
625401



1x
390001



1x
6093053



1x
4515347



1x
4520947



1x
6017003



1x
6092587



1x
4224793



2x
302421



5x
307021



2x
306221



1x
6092565



1x
609121



2x
614321



1x
300321




10x
302321



4x
371021



4x
366621



2x
346021



2x
302021



2x
4243814



2x
379521



12x
614121



4x
6072998



1x
6089698



1x
403221



6x
4521438



1x
4616800



7x
4600176



2x
486521



3x
302426



1x
302226



1x
6000650



3x
4529064



2x
4516020



1x
6081988



4x
614126



1x
4537251



1x
6035029



1x
6073040



6x
6069887



2x
6055384



14x
4613162



1x
4621557



6x
6101285



1x
6065504



11x
4523159



1x
6074906



2x
4541191



2x
4569058



2x
4543949



1x
4211166



2x
4585493



1x
6078236



7x
460026



1x
4619599



2x
4586057



1x
6060731



2x
4536675



3x
4650498



1x
243528



2x
6062010



1x
6031883



2x
4600267



6x
6024020



8x
6013102



2x
6062010



1x
4580007



4x
4167842



2x
4245570



2x
6037591



2x
306540



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555



: 1-800-422-5346